

Fuel Pumps Danfoss


Pump with Solenoid Valve




Coil

R+M Nr.	V
826 00	24 V
826 10	230 V

Intake monopipe or twinpipe.
Pressure adjustable 7 - 15 bar



R+M Nr.	TYP	coil	hub
825 45	BFP 21 L3	24 V	32 mm
825 40	BFP 21 L3	230 V	32 mm




R+M Nr.	TYP	coil	hub
825 35	BFP 21 R3	24 V	32 mm
825 30	BFP 21 R3	230 V	32 mm


Pump without Solenoid Valve



Intake monopipe or twinpipe.
Pressure adjustable 7 - 15 bar





R+M Nr.	TYP	coil	hub
825 20	BFP 20 L3	-	32 mm



R+M Nr.	TYP	coil	hub
825 10	BFP 20 R3	-	32 mm

Spare Parts Danfoss Fuel Pumps

	
Filter element	Filter cartridge
R+M Nr.	R+M Nr.
825 01	825 00

Accessories Fuel Pumps

Check Pressure Gauge



Undamped \varnothing 40 mm. Housing plastic. Hose connection 500 mm. Connection with O-Ring sealing

R+M Nr.	pressure range
547 105 0	0 - 16 bar

Cable with Connector




R+M Nr.	⊖
832 50	500 mm
832 40	1050 mm

Fuel Pumps SP

Pump with Solenoid Valve




Intake twinpipe.
Pressure adjustable 6 - 14 bar



K F

R+M Nr.	TYP	coil	hub
821 10	46L5316M	24 V	32 mm
821 20	46L5316M	230 V	32 mm




W

R+M Nr.	TYP	coil	hub
821 30	46L5416 M	24 V	32 mm
821 40	46L5416 M	230 V	32 mm

Pump without Solenoid Valve




Intake twinpipe.
Pressure adjustable 6 - 14 bar



K F

R+M Nr.	TYP	coil	hub
820 20	46L2386	-	32 mm



W

R+M Nr.	TYP	coil	hub
820 40	46L2486	-	32 mm

Filter Complete



R+M Nr.
822 40



R+M Nr.
822 15

Filter Element



R+M Nr.
822 50



R+M Nr.	V
821 024	24 V
821 220	230 V

Attention!

Rotating direction always stated in view of the shaft.

